

Anchorage Principle

The required bore roughness is directly related to the hardness and the mechanical characteristics of the base material. Depending on the combination of sealing plug and base material, anchorage takes place either by the groove profile of the expander sleeve biting into the base material or on anchorage to the surface roughness of the bore.

Note:

When selecting a KOENIG-Expander the bore roughness must always be adjusted according to the hardness of the base material.



Anchorage principle related to the base material

KOENIG-Expander



Hard base material: To achieve the allowable working pressure, anchorage to the bore roughness of the base material is required. Roughness $R_z = 10$ to 30 μ m.



Soft base material: Anchorage to the bore of the base material occurs automatically due to the serrations on the sleeve of the KOENIG-Expander.



Soft base material: Anchorage is not possible with the HK 55 and HK 11 Series. Such combinations are not allowed **for high pressure applications**.



Transition zone: To achieve the allowable working pressure, anchorage to the bore roughness of the base material is required. Roughness $R_7 = 10$ to 30 µm.



Transition zone: To provide for the allowable pressure rating, the serration of the sleeve, anchors into the base material.

Koenig Verbindungstechnik AG Tel ++41 1 743 33 33 Fax ++41 1 740 65 66









Anchorage due to plug sleeve serrations KOENIG-Expander **Series SK** in aluminum-alloy HB = 90

Anchorage due to plug sleeve serrations KOENIG-Expander **Series MB 800** in aluminum-alloy HB = 90





Anchorage due to bore roughness KOENIG-Expander **Series HK 55** in gray cast iron HB = 160

Anchorage due to plug sleeve serrations KOENIG-Expander **Series LP 900** in aluminum alloy HB = 90



Sufficient anchorage due to plug sleeve serrations KOENIG-Expander **Series LK 950** in aluminum alloy HB = 90



Koenig Verbindungstechnik AG Tel ++41 1 743 33 33 Fax ++41 1 740 65 66





Bore Roughness Requirements

When installing KOENIG-Expanders in hard base material no positive anchoring is possible. So, to attain suitable working pressures and anchorage, it is necessary to have a bore roughness of $Rz = 10 - 30 \mu m$. At a roughness greater than $Rz = 30 \mu m$ leakage might occur.

Pressure performance correlation to bore roughness.



Roughness Profile

Required roughness profile



The ideal bore roughness for anchorage is attained by drilling with a twist drill or core drill.

Undesirable roughness profile



By reaming, a one-sided, smooth roughness profile is created. This is not desirable.





Design Guidelines

Wall thickness/distance from edge

As the radial expansion of the KOENIG Expander sleeve occurs, the base material in which it will be anchored plastically deforms. The resultant strength, as well as the hydraulic pressure and temperature service conditions depending on the Expander type and characteristics of the base material, require minimum wall thickness, or distance from edge.



The guideline values for minimum wall thickness and distance from edge (W_{min}) express these influencing factors. At these minimum values, only slight deformation on the exterior profile of the base material of less than 20 µm is likely. This does not affect the function of the KOENIG Expander. Below the guideline values (W_{min}) the possibility of overloading the base material exists, which can adversely influence the function of the KOENIG Expander. In such cases tests must be conducted.

Guideline values W_{min} for wall thickness and distance from edge

At KOENIG-Expander diameters

 $d_1 \ddagger 4mm: W_{min} = f_{min} \cdot d_1$

 $d_1 < 4mm: W_{min} = f_{min} \cdot d_1 + 0.5 mm$

		1	2	3	4	5	6	\bigcirc
Base	Description	ETG 100	C15Pb	GG-25	GGG-50	AlCuMg2	AIMgSiPb	G-AlSi7Mg
Material	Avg. tensile strength [N/mm ²]	1000	560	250	500	480	340	300
	Min. elongation A5 [%]	6	6	-	7	8	8	4
	Avg. ultimate strength R _P 0,2 [N/mm ²]	865	300	-	320	380	300	250
KOENIG Expander Series		Factor f _{min.}						
MB 600		0,6	0,8	1,0	0,8	0,8	1,0	1,0
MB 600, Inch-Version		0,6	0,8	1,0	0,8	0,8	1,0	1,0
MB 700		0,6	0,8	1,0	0,8	0,8	1,0	1,0
MB 800		0,5	0,6	1,0	0,6	0,6	1,0	1,0
SK		0,5	0,6	1,0	0,6	0,6	1,0	1,0
HK 55		0,4	0,5	0,8	0,5	0,5	0,8	0,8
HK 11		0,4	0,5	0,8	0,5	0,5	0,8	0,8
LP 900		0,3	0,3	0,5	0,3	0,4	0,5	0,5
LK 600		on demand						
LK 950		on demand						





Design Guidelines



Roundness Tolerance

To assure reliable functioning of the KOENIG-Expander with regard to pressure performance and to assure leak tight sealing, a **roundness tolerance of t = 0.05 mm** must be held.



By using a double lipped twist drill, the called out hole and roundness tolerances are reached. Better tolerances, particularly for larger diameter holes, can be held by using a **triple lipped** twist drill.

Conicity of the bore

Within the **effective sealing area** of the KOENIG-Expander, the bore must be according to the dimesional sheets. The bore lead in can be beveled up to a depth of $0.25 \times d_1$ (LK: $0.15 \times d_1$) because this area has no significant effect on the sealing function.



Koenig Verbindungstechnik AG Tel ++41 1 743 33 33 Fax ++41 1 740 65 66